



Est 1990





Bolt/Flange nut

Only one bolt model is required for mounting your X-Tray system.

One M8 carriage bolt with a square shoulder to save you having to hold against when you tighten the nut. The bags are stand-up and re-closable.



Models

ARTICLES / DESCRIPTION	SURFACE TREATMENT
 2761 X61 Bolt M8x27	Black Zink
 2762 X62 Flange Nut M8	Black Zink
 7100-031 Expander Bolt M8x65	Zinc Plated
 7100-070 Self drilling screw, washer head 4.2x19	Zinc Plated